


SmartScreed WP

Waterproof Floor Screed

SmartScreed WP is a pre-packed cementitious waterproof floor screed powder. It consists of special cement, graded quartz sand and selected waterproofing additives. SmartScreed WP mortar is suitable for all new or old concrete substrate such as void decks, basement or any concrete substrate deemed necessary. When it is fully cured, SmartScreed WP serves as a strong and durable waterproof screed.



FIELDS OF APPLICATION

- Bathrooms & Toilets
- Kitchens
- Balconies
- Basements & Lift pits

BENEFITS

- Durable waterproof screed
- Shrinkage compensated
- One component, easy to use just mix with water and apply
- Good workalibity
- Weather Resistance

TECHNICAL DATA (under laboratory conditions)

PROPERTY		TYPICAL RESULTS
Compressive Strength		
ASTM C109 / 109M : 2016a		25 - 40 N / mm ²
Flexural Strength		
ASTM C348 : 2014		>2 N / mm ²
Water Absorption		
ASTM C413 : 2001 (2012)		< 5 %
Flow		
ASTM C1437 : 2015		80 % - 120 %
Shrinkage (Continho Ring)		No cracks
Water Penetration under		
DIN 1048 Pt 5 : 1991		
ADM / CE / 003 : 2010		< 5 mm
Water Retentivity		
BS 4551 : 2005 + A2 : 2013		> 90 %
Volume Change		
ASTM C827 / C827M : 2016		< 1 %
Stiffening Time (mins)	1.0 N / mm ²	≤ 360 minutes
BS EN 1015 - 9 : 1999 (Method A)	2.0 N / mm ²	≤ 420 minutes
Coverage per bag		0.55m²/kg/mm thickness

SURFACE PREPARATION

For New Concrete

- As soon as the concrete has set sufficiently to support a man's weight, it shall be textured with a deep cutting serrated bull float to produce grooves of 3mm in depth. Remove any scum or laitance. Cure the concrete with plastic sheet or water.
- Do not cure with curing compounds.
- New concrete must be at least 28 days before topping of SmartScreed WP.

For Old Concrete

- Old concrete must be sound, clean and roughened. Any oil, dirt, debris, paint and unsound concrete must be removed.
- The surface must be prepared mechanically using a scabbler, bushhammer, shotblast or scarifier which will give a surface profile of about 3mm and expose the large aggregate of the concrete.
- All cracks over 1.6mm wide should be routed out to a 6mm width and 6mm depth gap and should be pre-patched with SmartScreed WP before final topping of SmartScreed WP.
- The final step in cleaning should be the complete removal of all residues with a vacuum cleaner or pressure jet washer.

For Edges And Joints

- Edges should be sawcut 50mm wide x 6mm deeper than the topping thickness and chipped with a hand held chipping hammer to provide the wedge shaped notch.
- Moving joints as in the case of expansion joints should be brought up through the overlap by sawcutting or with the use of a divider strip.

DISCLAIMER

All information was prepared carefully, using current references available to us. Information provided is to the best of our knowledge and belief, accurate and reliable as of the date indicated. However, no representation, warranty or guarantee is made as to its accuracy, reliability or completeness. It is the user's responsibility to satisfy himself/ herself as to the suitability and completeness of information provided here for their intended use. We do not accept liability for any loss or damage that may occur from the use of this information.

Email: fengfu@ffpte.com



MIXING

- Hand-held electric drill mixer with paddle-head or pan mixer suitable for mortar mixing is recommended.
- Mix SmartScreed WP with 5 6 litres of clean water per 40 kg, depending on the consistency required.
- Always add powder to water during mixing.
- Mix for 3 to 5 minutes until a lump-free homogeneous consistency is obtained.

PLACING

- Place the well mixed SmartScreed WP onto pre-damped surface or onto pre-primed touch dry surface. A total minimum thickness of 20mm is recommended. It can be applied at a recommended thickness of 20 - 50 mm.
- SmartScreed WP should be well compacted and screeded to the required level with a fall where required.
- Avoid direct sunlight or strong wind during placing.

CURING & TREATMENT

- Proper curing is essential for long-term performance of the waterproof screed.
- Plastic sheets or wet hessians should be employed in curing for a minimum of 24 hours. Where the waterproof screed is to receive a topping thereafter, curing compound should not be used.

PRECAUTIONS

- Avoid eye and skin contact as the product is alkaline.
- Gloves, goggles and dust mask should be worn.
- Avoid inhalation of dust during mixing.
- Wash thoroughly after handling.
- In case of eye contact, flush with plenty of water.
 Seek medical help immediately.

PACKAGING & STORAGE

SmartScreed WP is supplied in 40 kg bags and has a shelf life of 12 months if stored in a cool and dry place in sealed packing with sheltered protection from rain and sunlight.

DISCLAIMER

All information was prepared carefully, using current references available to us. Information provided is to the best of our knowledge and belief, accurate and reliable as of the date indicated. However, no representation, warranty or guarantee is made as to its accuracy, reliability or completeness. It is the user's responsibility to satisfy himself/ herself as to the suitability and completeness of information provided here for their intended use. We do not accept liability for any loss or damage that may occur from the use of this information.

Email: fengfu@ffpte.com